

StormWise & ICPR4 Installation Guide

1. Download the Software:

- Access the legacy versions and corresponding release notes at [Legacy Downloads](#).

2. Installation Process:


- Open your firewall to icpr4.com HTTP Port 80.
- Run the setup.exe file and agree to all prompts, including "Slim DX" if it appears.

3. Internet Connection:

- An active internet connection is required for program authentication and use.

4. First-Time Authorization:

- Enter your serial number and password (provided at purchase) the first time you open the program.



5. Optional Silent Installation: Skip unless you want to limit interface with UI during installation

- This step is not recommended for StormWise installation since credentials need to be entered the first time the program is opened (i.e., manual entry of the serial number and password is required for the first authorization.)
- Use "**Advanced Installer**" with command line parameters for silent installations. More information at [Advanced Installer Guide](#).